

# SmartVoice™ Tower Fan

## Tower Fan ES 2907R

### VOICE COMMAND LIST

<b>Wake Word:</b>	<b>Activate Unit:</b>
Hey Fan	Fan On
	Turn On The Fan
	Fan Off
	Turn Off the Fan

### Oscillation Controls:

Rotate On / Off  
Rotation On / Off

### Speed Control:

Low Speed	Fan Medium
Low Fan	High Speed
Fan Low	High Fan
Medium Speed	Fan High
Medium Fan	

### Increase Speed:

Fan Speed Up

### Decrease Speed:

Fan Speed Down

### Set Timer:

Sleep in (between (1 – 15 hours)

### Cancel Timer:

Cancel Timer

Additional Commands on  
The back of the card

# SmartVoice<sup>TM</sup> Tower Fan

Tower Fan ES 2907R

## **Sleep Mode:**

Sleep Mode

## **Canceling Sleep Mode:**

Normal Mode

## **Turning Off Voice Controls:**

Voice Control Off

## **Turning On Voice Control:**

Voice Control On

## **Turning Off Voice Response:**

Voice Response Off

Note: Keeping active beep  
responses only

## **Turning On Voice Response:**

Voice Response On

For additional Commands and  
operating instructions. Please refer  
to the user manual provided.

### **Warning:**

Use indoors only

Do not leave the fan unattended

Do not use near water.

**NEED HELP?** Contact us at:

**Tech Suport Toll Free:** (888) 886-7188

**Email:** Support@emersonsmart.com

**Website:** [www.emersonsmart.com](http://www.emersonsmart.com)