

EMERSON SMARTVOICE TOWER FAN ES4201R

QUICK START GUIDE

Package contents

- SmartVoice Tower Heater (ES4201R)
- Remote Control
- User Manual
- Quick Start Guide

Note: Please refer to the full user manual for detailed operating instructions for the remote control and control panel.

Assembly

1. Connect the front base and the rear base together.
2. Press down on the edges to click the two (2) base halves in place.
3. Align and insert the bottom of the tower fan body into the opening on the top of the base.
4. Secure the base to the bottom of the tower fan body with the four included wing screws.

Let's get started with voice control

No app - no Wi-Fi - no hub required.

The SmartVoice Tower Fan has a built-in microphone for voice commands and a speaker to confirm commands and provide responses.

Voice control is ready once the fan is plugged into a wall outlet.

Wake word

The wake word activates voice control:

- "Hey Fan"

How to use voice control

1. Say the wake word. The fan will beep to confirm that voice control is active.
2. After the beep, you have 7 seconds to say a command from the Voice Commands section. After each command, the fan will confirm with a voice response and a beep.

Tips:

- After your first command, you can say another command within 7 seconds.
- If more than 7 seconds pass, say the wake word again before your next command.
- If the fan does not recognize a command, it will not respond and will continue operating with the current settings.

Voice commands

In this section, you will find:

- Commands you can say (spoken phrases) for certain functions.

Power

Commands you can say:

"Turn on the fan"

"Fan on"

"Turn off the fan"

"Fan off"

Speed

Commands you can say:

"Low speed"

"Low fan"

"Fan low"

"Medium speed"

"Medium fan"

"Fan medium"

"High speed"

"High fan"

"Fan high"

Adjusting speed

Commands you can say:

"Fan speed up"

"Fan speed down"

Oscillation

Commands you can say:

"Rotation on"

"Rotate on"

"Rotation off"

"Rotate off"

Timer

Commands you can say:

"Cancel timer"

"Sleep in X hours (1–15)"

"Set timer for X hours (1–15)"

Notes: Replace X with a number from 1 to 15.

Modes

Commands you can say:

"Normal mode"

"Sleep mode"

Voice responses

Commands you can say:

"Voice response on"

"Voice response off"

"Be quiet"

Voice control

Commands you can say:

"Voice control off"

"Voice control on"

Volume

Commands you can say:

"Volume down"

"Volume up"

"Volume all the way up"

"Volume all the way down"

Light

Commands you can say:

“Lights on”

“Lights off”

Contact

Refer to the user manual for more information on safety precautions, product instructions, maintenance, and more.

Tech Support (toll free): (888) 886-7188

Email: support@emersonsmart.com

Website: emersonsmart.com

Legal

Manufactured and sold by IAI Smart Inc. The Emerson logo is licensed by IAI Smart Inc.

SmartVoice is a trademark of IAI Smart Inc. in the US.

All other products, brand names, company names, and logos are trademarks of their respective owners. They are used only to identify their respective products and do not imply sponsorship, endorsement, or approval.

©2025 IAI Smart Inc. All Rights Reserved.

WARNING: Use indoors only. Do not leave the heater unattended while in use.