

SmartVoice™ Tower Fan

QUICK START GUIDE

PACKAGE CONTENTS

User
Manual



Remote
Control



Tower
Fan



• Please refer to the manual for operating instructions on using the remote control and control panel.

ASSEMBLY



Connect the base halves together. Press down on the edges to click the two (2) base halves in place.



Unscrew the lock nut, removing it from the bottom of the tower fan body.



Thread the power cord through the opening in the base and insert the bottom of the tower fan body into the base.



Thread the power cord through the lock nut. Then, fasten the lock nut to the base.

LET'S GET STARTED WITH VOICE CONTROL

No App · No Wi-Fi · No Hub required

The SmartVoice Tower Fan is equipped with a microphone to listen to voice commands and a speaker to confirm and respond to received commands.

Voice control is ready for use once the SmartVoice Tower Fan is connected to a wall outlet.

The wake word is the phrase that activates the voice control function.

To control the SmartVoice Tower Fan with voice commands, follow the next two steps:

- 1 Say the wake word, the fan will beep to confirm activation of the voice control function.
- 2 After hearing the beep, you will have 7 seconds to use one of the commands listed on the back. After each command, the fan will confirm the command with a voice response and a beep.
 - Once the initial command is given, you can give another command within 7 seconds of the previous one.
 - If another command is not given within 7 seconds of the previous one, say the wake word before giving a new voice command.
 - If the fan does not recognize a voice command, it will not respond and continue operating according to its current settings.

CONTACT

Refer to the user manual for more information on safety precautions, product instructions, maintenance, and more.

Tech Support Toll Free: **(888) 886 -7188**

E-mail: **Support@emersonsmart.com**

Website: **www.emersonsmart.com**

Manufactured and sold by IAI Smart Inc., the Emerson logo is licensed by IAI Smart Inc. SmartVoice is a trademark of IAI Smart Inc. in the US. All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement, or approval.

©2025. IAI Smart Inc. All Rights Reserved.

WARNING! Use indoors only. Do not leave the fan unattended while in use.

ECL4007RBL

VOICE COMMANDS

<u>Function</u>	<u>Voice Command</u>
Wake voice control	Hey fan
Turning on the fan	Turn on the fan Fan on
Turning off the fan	Turn off the fan Fan off
Setting low fan speed	Low speed Low fan Fan low
Setting medium fan speed	Medium speed Medium fan Fan medium
Setting high fan speed	High speed High fan Fan high
Increasing fan speed	Fan speed up
Decreasing fan speed	Fan speed down
Starting oscillation	Rotate on Rotation on
Stopping oscillation	Rotate off Rotation off
Setting timer	Sleep in (choose between 1 to 15) hours
Canceling timer	Cancel timer
Activating sleep mode	Sleep mode
Canceling sleep mode	Normal Mode
Turning on device's voice controls	Voice control on
Turning off device's voice controls	Voice control off
Turning on device's voice responses	Voice response on
Turning off device's voice responses (keeping active beep responses only)	Voice response off
Turning off beep and voice responses	Be quiet