

SmartVoice™ Fan-Heater

QUICK START GUIDE

PACKAGE CONTENTS

User
Manual



Remote
Control



Fan-Heater



• Please refer to the manual for operating instructions on using the remote control and control panel.

LET'S GET STARTED WITH VOICE CONTROL

No App · No Wi-Fi · No Hub required

The SmartVoice Fan-Heater is equipped with a microphone to listen to voice commands and a speaker to confirm and respond to received commands.

Voice control is ready for use once the power switch of the SmartVoice Fan-Heater is flipped to the "ON" position.

The wake word is the phrase that activates the voice control function.

To control the SmartVoice Fan-Heater with voice commands, follow the next two steps:

- 1 Say the wake word, the heater will beep to confirm activation of the voice control function.
 - 2 After hearing the beep, you will have 7 seconds to use one of the commands listed on the back. After each command, the SmartVoice Fan-Heater will confirm the command with a voice response and a beep.
- Once the initial command is given, you can give another command within 7 seconds of the previous one.
 - If another command is not given within 7 seconds of the previous one, say the wake word before giving a new voice command.
 - If the SmartVoice Fan-Heater does not recognize a voice command, it will not respond and continue operating according to its current settings.

CONTACT

Refer to the user manual for more information on safety precautions, product instructions, maintenance, and more.

Tech Support Toll Free: **(888) 886 -7188**

E-mail: Support@emersonsmart.com

Website: www.emersonsmart.com

Manufactured and sold by IAI Smart Inc., the Emerson logo is licensed by IAI Smart Inc. SmartVoice is a trademark of IAI Smart Inc. in the US. All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement, or approval.

©2025. IAI Smart Inc. All Rights Reserved.

VOICE COMMANDS

Function

Voice Command

Wake voice control	Hey heater
Turning on the heat Note: The heater will activate in low mode.	Turn on Power on
Turning off the heater Note: The heater will turn off and the fan will continue to run for 30 seconds to cool the unit.	Heat off Turn off Shut down Power off
Increasing the heat	Heat up High heat
Decreasing the heat	Low heat Heat down
Starting oscillation	Rotate on Rotation on
Stopping oscillation	Rotate off Rotation off
Setting timer	Set timer for (choose between 1 to 7) hours Sleep in (choose between 1 to 7) hours
Canceling timer	Cancel timer
Turning on device's voice controls	Voice control on
Turning off device's voice controls	Voice control off
Turning on device's voice responses	Voice response on
Turning off device's voice responses	Voice response off
Increasing voice volume	Volume up
Decreasing voice volume	Volume down
Raising voice to maximum volume	Volume all the way up
Lowering voice to minimum volume	Volume all the way down