

# EMERSON SMARTVOICE WALL PLUG ES513

## QUICK START GUIDE

### Package contents

- SmartVoice Wall Plug (ES513)
- User Manual
- Quick Start Guide

Note: Please refer to the full user manual for detailed operating instructions for the remote control and control panel.

### Let's get started with voice control

No app - no Wi-Fi - no hub required.

The SmartVoice Wall Plug has a built-in microphone for voice commands and an LED light that confirms received commands.

Voice control is ready once the wall plug is plugged into a wall outlet.

### Wake word

The wake word activates voice control:

- "Hey Emerson"

### How to use voice control

1. Say the wake word. The wall plug will beep to confirm that voice control is active.
2. After the beep, you have 7 seconds to say a command from the Voice Commands section. After each command, the wall plug will confirm with a voice response and a beep.

### Tips:

- After your first command, you can say another command within 7 seconds.
- If more than 7 seconds pass, say the wake word again before your next command.

- If the wall plug does not recognize a command, it will not respond and will continue operating with the current settings.

## Voice commands

In this section, you will find:

- Commands you can say (spoken phrases) for certain functions.

Note: The wall plug can only respond to commands listed below.

### Power control

Turn ON (after saying the wake word):

- "Turn on"
- "Lights on"
- "Power on"
- "Power up"

Turn OFF (after saying the wake word):

- "Turn off"
- "Lights off"
- "Power off"
- "Power down"

### Cancel timers

- "Cancel timer"
- "Cancel sleep"
- "Cancel wake"

### Set a timer to turn OFF

Say one of the following after the wake word. Replace the time with one option shown:

- "Sleep in 15 minutes" (or 30 minutes, or 45 minutes)
- "Sleep in 1 hour" (or 2 hours, 4 hours, 8 hours, 12 hours)
- "Set timer for 15 minutes" (or 30 minutes, or 45 minutes)
- "Set timer for 1 hour" (or 2 hours, 4 hours, 8 hours, 12 hours)

### Set a timer to turn ON

Say one of the following after the wake word. Replace the time with one option shown:

- "Wake in 15 minutes" (or 30 minutes, or 45 minutes)
- "Wake in 1 hour" (or 2 hours, 4 hours, 8 hours, 12 hours)

## Contact

Refer to the user manual for more information on safety precautions, product instructions, maintenance, and more.

Tech Support (toll free): (888) 886-7188

Email: [support@emersonsmart.com](mailto:support@emersonsmart.com)

Website: [emersonsmart.com](http://emersonsmart.com)

## Legal

Manufactured and sold by IAI Smart Inc. The Emerson logo is licensed by IAI Smart Inc.

SmartVoice is a trademark of IAI Smart Inc. in the US.

All other products, brand names, company names, and logos are trademarks of their respective owners. They are used only to identify their respective products and do not imply sponsorship, endorsement, or approval.

©2025 IAI Smart Inc. All Rights Reserved.

**Warning: Use indoors only. Do not expose to water.**